

CORDOVA SAFETY · MODEL 4522



Premium Green Nitrile Glove

Unlined · 22-mil · Pebble Grip · 18-inch length

Premium unsupported nitrile glove built for heavy chemical handling, HazMat cleanup, food-processing lines, and petrochemical work. Manufactured with FDA-accepted materials (21 CFR Parts 170–199) for direct food contact. Pebble grip retains bite when wet with oils or hydrocarbons. Full 18" gauntlet protects the forearm against splashes.

Sterile Mate Retail: \$189.00 / dozen · \$1,134.00 / case (6 dozen) · freight not included

22-mil
Thickness

18"
Length

6 dz
Per Case

EN388
Certified

FDA
Food Contact

Description

Unsupported gloves are manufactured on ceramic formers with embossed grip patterns, dipped directly into protective polymers with no supporting fabric or liner. Palm thicknesses in this class typically range from 11 to 30 mil.

Nitrile is a synthetic rubber developed as a substitute for natural rubber. It protects against organic solvents, oils, bases, and animal fats. This **22-mil premium unsupported nitrile glove** is unlined and features an **18-inch length** with a **pebble grip** that retains traction in wet, oily, or greasy conditions.

Features

- Premium unsupported nitrile construction — heavy 22-mil (0.56 mm) palm thickness
- 18-inch (46 cm) full-forearm gauntlet length for splash protection
- Pebble grip texture on palm and fingers for oil / hydrocarbon retention
- Unlined interior for maximum dexterity and easier donning / doffing
- Green color — high-visibility against food and processing lines
- Straight cuff — rolled bead for tear resistance
- Manufactured on ceramic formers for consistent thickness and even coverage
- Made with FDA-accepted materials for direct food-contact applications
- Sold by the pair · 12 pairs per dozen · 6 dozen per case

Applications

Food Processing	Red meat, poultry, and dairy handling lines
Printing	Ink and solvent handling
Painting	Solvent and coating application
Petrochemical	Handling hydrocarbons — oil, grease, gasoline
Janitorial / EVS	Chemical restocking, heavy sanitization
HazMat	Spill cleanup, decontamination lines
Agriculture	Herbicide, fertilizer, and animal-fat handling

Performance Ratings (CE EN388 — Mechanical Hazards)

Hazard	Rating
Abrasion	Level 4
Blade Cut	Level 1
Tear	Level 0
Puncture	Level 1

Models & Sizing

Part Number	Size	Pack	Case
4522S	Small	12 pairs / dozen	6 dozen
4522M	Medium	12 pairs / dozen	6 dozen
4522L	Large	12 pairs / dozen	6 dozen
4522XL	X-Large	12 pairs / dozen	6 dozen
4522XXL	2X-Large	12 pairs / dozen	6 dozen

Regulatory & Food-Contact Compliance

Made with FDA-accepted materials for food-contact applications.

U.S.: Code of Federal Regulations, 21 CFR Parts 170–199

Europe: CE Directive 89/109/EEC

Mechanical protection: CE EN388 tested (Abrasion 4 / Cut 1 / Tear 0 / Puncture 1)

Prop 65: No warning required

Sterile Mate Pricing

Unit	Retail Price	Notes
Per Dozen (12 pairs)	\$189.00	Freight not included
Case (6 dozen • 72 pairs)	\$1,134.00	Freight not included • palletized

Request a Quote

Web: sterilemate.com/marketplace · Email: orders@sterilemate.com · Phone: 800.988.3892

GSA, cooperative-contract, and MBE / HUB pricing available. Multi-case and PO quotes returned within one business day.